

7 step guide to OSMOUK Post Fix success –

1. Dig a hole. Make sure there is no water standing in the hole.
2. Prepare the mixture by mixing Part A and Part B.
3. Shake the bottle for 20 seconds.
4. Pour the solution into the hole, with the post firmly in place.
5. Watch the solution expand in the hole, securing the post in the desired position.
6. Cut away any excess solution.
7. Cover with sand.

